

REMOVING THE MOP HEAD FOR CLEANING:

1. Step on the threads of the mop head near the edge of the disk (fig 8).

NOTE: Make sure you do not step on the disk.

2. Push the handle away from the body as shown. This separates the disk from the mop head.



Fig. 8

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product.

TeleBrands Corporation shall not be liable for any incidental or consequential damages or any implied warranty on this product.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



Instruction Guide



Scan
For More
Information



Fairfield, NJ 07004

www.Telebrands.com

Made in China. • ©2013Telebrand Corp.

TBHSMM080613




WARNING!

Keep hair, hands and other body parts away from the wringer.
Failure to follow these instructions may result in possible INJURY.


ASSEMBLY INSTRUCTIONS

1. Before assembling, please make sure you have all parts listed above.
2. Screw the top handle onto the middle handle by holding the middle handle and turning the top handle clockwise.
3. Attach the bottom handle by holding the bottom handle and turning the middle handle clockwise.
4. Attach the disk by holding the disk and turning the bottom handle clockwise (fig. 1).
5. To assemble mop head, lay the mop head on the floor. Place the disk on top of the mop head and press down until the mop head snaps into place (fig. 2).

Your Spin Mop is ready for use!



IMPORTANT: Make sure that the bottom handle and disk are securely tightened.




USAGE INSTRUCTIONS

Adjust Angle:

1. The angle of the handle can be adjusted from 45 to 180 degrees.
2. Simply move the handle back and forth (fig. 3).

(continued on next page)



USAGE INSTRUCTIONS (continued)

Maximum Water Level:

Do not fill past "full water level" mark (fig. 4) to prevent overflow when wringing out the mop.

Dry/Wring Feature:

1. When placing the mop head into the wringer, keep the handle vertical (fig. 5) for the disk to rotate properly.
2. To dry or wring out your mop head, place the mop head flat in the wringer side of the bucket (fig. 6). Hold the grip handle (fig. 7), then press the foot pedal. The wringer will dry the mop head.

Damp Control:

You can control how wet the mop head is by spinning off excess water in the wringer until the desired dampness of the mop head is achieved. This allows the mop to be used for different jobs like cleaning, dusting, or spills.

CARE INSTRUCTIONS

1. You will find that the mop head (100% Polyester) can easily be cleaned by simply rinsing in clean water (or adding your favorite detergent to the water). Wash the mop head in the bucket, then place in the wringer and spin.
2. Occasionally, you may want to clean the mop head by simply throwing it in the washing machine. Follow the instructions below 'Removing The Mop Head For Cleaning.' Place in washing machine on gentle cycle, using hot water and regular detergent. You may want to add regular or color safe bleach if necessary. DO NOT use fabric softeners or put in an automatic dryer. Let air dry.

NOTE: DO NOT put the mop head in an automatic dryer.

